





# WHITE WEASEL™ MOBILITY 3G | 4G | LTE ACCESSPOINT & ROUTER

## Quick Installation Guide

### Hardware Installation

#### A. Hardware configuration



## B. Installation Steps



**Note:** ***DO NOT*** connect the router to power before performing the installation steps below.

### **Step 1.**

Plug a USB modem into USB port.



### **Step 2.**

Insert RJ45 cable into LAN Port on the back panel of the router. Then plug the other end of into computer.



### **Step 3.**

Plug the power jack into the receptor on the back panel of the router. Then plug the other end into a wall outlet or power strip.



# Getting Started with Easy Setup Utility

There are two approaches for you to set up the WiFi Combo Router quickly and easily. One is through executing the provided Windows Easy Setup Utility on your PC, and the other is through browsing the device web pages and configuration.

## Easy Setup by Windows Utility

### Step 1 :

Install the Easy Setup Utility from the provided CD then follow the steps to configure the device.


### Step 2 :

Select Language then click "Next" to continue.



### Step 3 :

Then click the "Wizard" to continue.




**Step 4 :**

Click "Next" to continue.

**Prepare Setup**  
This step will make sure connection can be established between your PC and router

Please make sure the following items.

1. Make sure the router is powered on.
2. Make sure your network adapter is connected to the LAN port of the router.
3. Make sure your network adapter has an IP address.



Help < Back Next > Cancel

**Step 5 :**

Select Wireless Enable, and then click "Next" to continue.

This step will setup your basic wireless network settings.

This will provide you with a basic workable setting for your wireless. You can also select to do it later.

Wireless:

Do not set at this time.

Help < Back Next > Cancel

**Step 6 :**

Enter SSID, Channel and Security options, and then click "Next" to continue.

This step will setup your basic wireless network settings.

Please assign the parameters to your wireless networking. If you need more settings, please login to the Gateway's configuration page.

SSID:

Channel:


Security:

Key:

Help < Back Next > Cancel


**Step 7 :**

Click " Let me select WAN service by myself" to select WAN service manually.




**Step 8 :**

Select 3G Service by clicking 3G icon to continue.



**Step 9-1 :**


Select "Auto-Detection" and the Utility will try to detect and configure the required 3G service settings automatically. Click "Next" to continue.



**Step 9-2 :**

Or you can select “Manual” and manually fill in the required 3G service settings provided by your ISP.

Click “Next” to continue.



**WAN Setting**  
3G Service

Please input the WAN service information.


Dial-Up profile  
 Auto-Detection  Manual

PIN Code:  (Optional)  
APN:  (Optional)  
Dialed Number:   
Username:   
Password:

Help < Back Next > Cancel

**Step 10:**

Click “Next” to save your setting.



**Save Settings**

The settings will be saved to the Router and reboot at the next step.

SSID:default  
Channel:11  
Security:WEP


**WAN Setting (3G Service)**  
APN:1234  
PIN Code:internet  
Dialed Number:\*99#  
Username:Admin  
Password:1234

Modify Settings

Help < Back Next > Cancel

**Step 11 :**

The WiFi Combo Router is rebooted to make your entire configuration take effect.




**Save Settings**

Reboot router...

Help < Back Next > Cancel


**Step 12 :**

Click "Next" to test the Internet connection or you can ignore test.



**Step 13 :**

Click "Next" to test WAN Networking service.



**Step 14 :**

Setup is completed.

