

# **Ednet Wireless Combo 2.4 GHz**



**Manual** 86265

Read all instructions before use the product and keep this manual for future references

#### How to connect it to computer

- 1. Remove the battery cover of the keyboard and install it with 2 pcs AAA batteries. Put back the cover.
- 2. Remove the battery cover of the mouse and install it with 2 pcs AAA batteries. Put back the cover.
- 3. The mouse has an ON/OFF switch located on the bottom surface. Make sure it is in the "ON" position.
- 4. Take out the nano receiver from the mouse and plug it onto the USB port of the computer.
- 5. The computer will then connect those devices automatically.

#### How to pair the keyboard and mouse manually

The mouse and keyboard are paired during production. You can also manually pair them as per below:

- 1. Make sure keyboard and mouse are with battery installed
- 2. Plug the nano receiver into computer USB port
- 3. Press ESC+K on keyboard
- 4. The keyboard and mouse will be paired automatically.

#### **Product Description**

Connection: USBFrequency: 2.4GHz

Number of keys: 105 normal keys + 10 multimedia keys

Distance of operation: 8-10 m

Power Source: Keyboard - 2 x AAA, Mouse - 2 x AAA (batteries not included)

Keyboard with spill proof design.

CPI: 800-1200-1600 DPI

### **System Requirements**

Compatible with Windows XP, Vista, W7, W8, Mac OS X 10.4 or above

#### **Technical information**

• Material: ABS

• Net weight: Keyboard 0.435 kgs | Mouse 0.06 kgs

● **Product Size**: Keyboard 440\*123\*27MM | Mouse 108\*74\*38MM

• Voltage: 3VDC

## 10 hot keys features:

$\sim$	E-Mail	Press this key to activate the default e-mail system
<b>A</b>	Home	Press this key to go to the default Home Page
<b>b</b>	Favorites	Press this key to open favorites to check files
Q	Search	Press this key to search files from "My Computer"or "My files"
0	Refresh	Press this key to refresh the website which is viewed
1	Media	Press this key to open the default media system
<b>–</b>	-Volume	Press this key to decrease the volume
	Mute	Press this key to mute/resume the sound
<b>4</b> +	Volume	Press this key to increase the volume
<b>►/</b> II	Play/Pause	Press this key to begin playing media or pause the media