



# **eSATA CARDBUS ADAPTER**



## **User Manual**

## ***Features and Benefits***

- Silicon Image SiI 3512 chipset
- Compliant with Serial ATA Specifications rev. 1.0
- PCMCIA CardBus Interface with Power Management
- Provides two independent channels to support to two Serial ATA drives
- Support Serial ATA data transfer rates up to 150MB/sec
- Breaks the 137GB barrier! Supports various brands of large capacity Serial ATA hard disk drives
- Supports Windows 7, Vista, XP, 2000

## ***Bus Interface***

- 32-bit PCMCIA Type II

## ***Connectors***

- 2 x external eSATA connectors

## ***System Requirements***

- Windows 7, Vista, XP, 2000
- Available CardBus Type II Slot

## ***Hardware Installation***

General instructions for installing the card are provided below. Since the design of system may vary, refer to your system's reference manual for further information, if needed.

1. Power off your notebook computer.
2. Insert the eSATA CardBus Adapter into the Type II PC Card slot of your notebook computer. Make sure it is inserted all the way in for a solid connection.
3. Power on your notebook computer.

## ***Driver Installation***

### ***For Windows® 2000***

1. At **Found New Hardware Wizard**, click **Next**.
2. Select **Search for a suitable driver for my device(recommend)** then click **Next**.
3. Insert the driver CD, check **CD-ROM drives**, uncheck the other boxes, click **Next**, then click **Next** again.
4. If the **Digital Signature Not Found** message appears, click **Yes**.  
Our driver has been thoroughly tested for stability and

compatibility.

5. Click **Finish**.

### ***For Windows® XP/Server 2003***

1. At the **Found New Hardware Wizard**:  
XP(w/SP1 or earlier)/Server 2003: continue to step #2  
XP(w/SP2 or later)/Server 2003(w/SP1 or later): select **No, not this time**, then click **Next**.
2. Insert the driver CD, select **Install the software automatically (Recommended)**, and click **Next**.
3. Click **Finish**.

### ***For Windows® Vista***

1. At **Found New Hardware Wizard**, select **Locate and install driver software (recommended)**.
2. Insert the driver CD, click **Next**.
3. If the system prompts the user informing the drivers are not signed, select the option **Install this driver software anyway**.
4. Click **Close** to complete the installation.

## ***To Verify Windows® Installation***

1. Right click **My Computer** and click **Manage**.
2. Select **Device Manager**.
3. Double click **SCSI and RAID Controller**, then double click **Silicon Image SiI 3512 SATALink Controller** to display driver properties. A message this device is working properly is displayed in the dialog box, the driver has been correctly installed.